



Application Note on the Use of a Controller Area Network (CAN) and Application Program Interface (API)

This application note offers definitions of NovAtel's CAN and API features. It also explains how to utilize the API properly for transmitting or receiving one of two types of CAN frames.

References to footnote numbers that appear in square brackets are at the back of this application note on *Page 13*.

The CAN Protocol

The CAN protocol is a means for devices (nodes) to communicate with one another efficiently and robustly. Originally designed for automotive applications, it uses robust physical signaling methods to ensure low error rates in the presence of ground loops, voltage mismatches, and otherwise poor signal environments. CAN nodes, known as ECU's (Electronic Control Units) co-exist on a 2-wire differential signaling bus. Each end of the bus terminates with a 120-ohm impedance to ensure proper signal balance, see *Figure 1* below.




Figure 1 CAN Physical Layers

The term "CAN bus" is widely used to describe an entire system of interconnected devices.

CAN permits nodes of unequal capability to share a network. This has proven to be an essential attribute in vehicular systems where low-complexity/low-rate temperature sensors must co-exist on a bus with high-rate, high complexity sensors such as wheel slip or steering wheel angle sensors.

Background

The CAN protocol has evolved out of network definitions pioneered by Robert Bosch GmbH and first introduced in 1996 as CAN 1.0 with an 11-bit identifier (standard message frame).^[1]

CAN is a series of standards. The ISO 11898-1 standard, defines the physical layer (hardware), data link layer (message formatting) of the CAN standard and extended messages. ISO 11898-2 defines high-speed operations between 125 kbps to 1000 kbps. In practice, the standards are identical in physical signaling and framing. They differ in the higher levels of communication, including networking and application layers.

As an example, J1939 (defined by the SAE – Society of Automotive Engineers) and ISO 11783 (defined by the ISO – International Standards Organization) refer to a series of standards specifically targeting interoperability in the agricultural industry, including operation with a virtual terminal. ISOBUS is an agricultural industry initiative to define minimum levels of interoperability against the ISO 11783 standard.

As an example of using CAN for higher-level applications, some agricultural auto-steering applications make extensive use of CAN. The guidance application communicates with the tractor control functions through the 11783 protocol and CAN-capable steering valves. As guidance functions become more sophisticated, higher levels of ISO 11783 define the operation that implements and controls engine and hydraulic systems to permit automatic turning.

NEMA 2000 is a CAN standard supported by the National Marine Electronics Association and designed to support networking in marine applications. It functions over a longer physical distance, and supports more physical nodes than ISO 11783. The precise differences are outside the scope of this document.

The challenge for a systems integrator is to ensure that the CAN bus protocol can interpret appropriate messages from a vehicle. The CAN standards permit manufacturer-defined messages, and integrators will find that some knowledge of these manufacturer-defined messages is necessary for advanced CAN control. However, key positioning messages related to position, velocity, and time are defined publicly in the standards.

A number of CAN protocol stacks are available as third-party applications. Higher-level software protocols such as CANOpen^[2] and DeviceNet^[3] are available for development from third party software companies.

The NovAtel API^[4] developer selects the appropriate protocol stack, be it for agriculture, automotive or aerospace applications. The developer can then gain access to the computing resources and CAN supporting hardware on a NovAtel OEM positioning engine. NovAtel's OEMV-3 GNSS receiver includes a full CAN 2.0B processor, as well as the physical-level transceivers for differential signaling. The OEMV-1 and OEMV-2 GNSS receivers include the full CAN 2.0 processor but require transceivers external to the board.

The CAN Frame

The OEM CAN API operates at the level of the CAN frame. *Figure 2 on Page 3* shows a simplified overview of the CAN frame.

CAN frames are defined as either standard or extended. Each frame is marked by a unique CAN protocol header, see *Figure 3 on Page 3*, designating the number of bits used to encode the frame ID field. The standard frame type has an 11-bit 'frame ID' field in the CAN protocol header while the extended frame type has a 29-bit ID field permitting a much larger number of CAN message types. The API has support for both frame types.

The configuration of CAN frame filters and the transmission of CAN frames depends on the frame type selected for use in the target CAN network. This application note explains how to utilize the API properly for transmitting or receiving CAN frames of either type.




Figure 2 Simplified Overview of a CAN Frame




Figure 3 Protocol Layers

NovAtel's CAN Interface

Features

- OEMV-3 supports two independently configurable CAN ports (only one CAN port on the OEMV-2 card)
 - The CAN 2.0B processor in the NovAtel receivers supports multiple bus rates from 10 kbps to 1000 kbps. It is important to note that while the CAN processor supports the full CAN 2.0B processor specification, the effective bus rate, supported by J1939, is up to 125 kb/s, while ISO 11783 supports up to 500 kb/s.
 - The CAN 2.0B processor in the NovAtel receivers supports the definition of message and frame masks or filters. Since each node in the CAN bus can listen to all other nodes, it is necessary to filter bus traffic for messages destined only for the CAN application in the receiver. The CAN 2.0B processor supports:
 - up to 31 unique filters for extended frames (16 “hard” and 15 “soft” filters)
 - up to 16 unique filters for standard frames (hard filters only)

See also the *Special Notes on Filtering* section, starting on *Page 10*, for more information on hard and soft filters.

Physical Interface

The NovAtel OEM positioning engine provides one or two CAN ports, depending on the model. OEMV-1, OEMV-1G and OEMV-2 ports consist of pairs of TTL-level signals (transmit and receive) to which the system integrator must connect the appropriate bus driver hardware as shown in *Figure 4* on *Page 5*. The OEMV-3 has two CAN transceivers, CAN1 and CAN2, but proper off-board bus termination is still required. Refer to the *Technical Specifications* appendix in the *OEMV Family Installation and Operation User Manual* for OEMV card pin-outs.^[5]

The choice of driver depends on the physical layer implementation of the target CAN bus network. A common physical layer standard is ISO 11898^[6] that describes a 2-wire differential bus configuration. Bus drivers are available from many different manufacturers.

Software (User) Interface

NovAtel provides an optional OEM Application Program Interface (API) to allow customers to write software to connect the NovAtel OEM positioning engine to their CAN network. Configuration for this option is through NovAtel's model definitions for the cards. If enabled, the API provides a collection of functions that enable the system integrator to send and receive CAN frames. The system integrator is required to implement any higher-level protocols and functionality (DeviceNet, and so on) on top of the API.

The CAN portion of the API groups interface functions into these three categories:

1. Configuration
2. Transmission
3. Reception




Figure 4 NovAtel's CAN Bus Interface

NovAtel's CAN API

The following sections provide a detailed API function reference. Refer also to the *API User Manual*, available from NovAtel Customer Service if the receiver is an API-capable model. It contains information on working with the API to be able to develop applications for NovAtel's OEM4/OEMV families of receivers. It provides information on building and loading applications. The system integrator can find other API function details in the API header file.

Configuration

Configure a CAN port for transmission or reception by using the following function calls:

- OEM4API_CANXOpen
- OEM4API_CANClose
- OEM4API_CANAddSWFilter
- OEM4API_CANClearAllSWFilters

CANXOpen

BOOL

```
OEM4API_CANXOpen(
    CANPortEnum ePort_,
    CANBitRateEnum eBitRate_,
    HardCANFilterStruct* pstFilter_,
    int iPriority_);
```

```
typedef enum
{
    CANBI TRATE_10K   = 0,
    CANBI TRATE_20K   = 1,
    CANBI TRATE_50K   = 2,
    CANBI TRATE_100K  = 3,
    CANBI TRATE_125K  = 4,
    CANBI TRATE_250K  = 5,
    CANBI TRATE_500K  = 6,
    CANBI TRATE_800K  = 7,
    CANBI TRATE_1M    = 8
} CANBi tRateEnum;
```

```
typedef enum
{
    CANPORT1 = 1,
    CANPORT2 = 2
} CANPortEnum;
```

```
typedef struct
{
    BOOL bInUse;
    BOOL bExtended;
    unsigned long ulAcceptanceCode;
    unsigned long ulAcceptanceMask;
} HardCANFi lterStruct;
```

A CAN port, `ePort_`, on the NovAtel OEM positioning engine is opened and initialized to the specified rate `eBi tRate_`. In addition, up to 16 CAN 'hard' frame filters, `pstFi lter_`, are initialized in the CAN protocol hardware. At least one filter must be enabled (`bEnabl ed = TRUE`) for any CAN frames (data) to be received into the application.

Hard filters exist within the CAN protocol hardware. These filters do not take any CPU cycles to function and are thus preferred over 'soft' filters (see the *CANAddSWFilter* section below for more details).

Do not use the `i Pri ori ty_` field on OEMV platforms but leave as zero (0).

CANClose

BOOL

```
OEM4API _CANCI ose(
    CANPortEnum ePort_ );
```

This command disables the specified port, `ePort_`, and no longer communicates with the CAN bus. Additionally, it removes power to the CAN protocol hardware. To open the port again, the command `CANXOPEN` must be re-asserted.

CANAddSWFilter

BOOL

```
OEM4API _CANAddSWFi lter(
    CANPortEnum ePort_,
    SWCANFi lterStruct* pstFi lter_ );
```

The software filters have two purposes: to filter CAN frames based on the *data* portion of the frame, or to implement more than the 16 filters provided by the hard filter mechanism. Call this function up to 15 times per `ePort_` to add a maximum of 15 soft filters referenced by `pstFi lter_`. If the system integrator adds at least one soft filter, the soft filters are considered

enabled and any received CAN frames must pass the soft filters to be visible to the reception functions.

CANClearAllSWFilters

BOOL

```
OEM4API_CANClearAllSWFilters(
    CANPortEnum ePort_ );
```

This function clears all software filters that have been set for the specified ePort_. Consequently, all received CAN frames passing the hard filters are visible to the reception functions.

Frame Transmission

The contents of a CAN frame to be transmitted are specified in a CANMsgStruct structure. The system integrator must fill out this structure with the necessary frame ID and frame data. Then use the following function calls to facilitate frame transmission:

- OEM4API_CANSend

CANSend

BOOL

```
OEM4API_CANSend(
    CANPortEnum ePort_,
    CANMsgStruct* pstCANMsg_,
    BOOL bBlock_ );
```

```
typedef struct
{
    unsigned long ulMsgID;
    BOOL bExtended;
    unsigned int iLength;
    unsigned char aucData[8];
} CANMsgStruct;
```

The CANSend function attempts to immediately transmit the CAN frame specified in pstCANMsg_ to the CAN port indicated by ePort_. The CAN frame must have its frame ID set in ulMsgID and the frame type set in bExtended (TRUE = extended, FALSE = standard). The frame ID can range from 0 to 2047 (0x0 to 0x7FF) for standard frames or from 0 to 536,870,911 (0x0 to 0x1FFF FFFF) for extended frames. From 0 to 7, fill data bytes in and assign them to aucData, and the corresponding number of data bytes set in iLength.

If a previous transmission request is in progress, the frame is automatically placed into a 32-frame transmit queue. Transmission of the queued frame proceeds immediately after the current transmission is complete. Note that frame transmission can only proceed once the CAN bus is available, that is, no other nodes are transmitting at that time.

If the bBlock_ parameter is TRUE and the 32-frame queue is full, the CANSend function call causes the task to block until a slot in the frame queue becomes available. If the bBlock_ parameter is FALSE, transmitted frames drop if the queue is full.

Practically speaking, the `bBlock_` parameter has no effect and the chance of dropping a frame is zero unless 33 or more frames transmit in a single burst. Define a frame burst as a repeating loop of `CANSend` function calls without an `OEM4API_TaskSleep` call in the loop.

For example, avoid the following frame burst would result in the 33rd frame dropping.

```
For(int i = 0; i < 33; i++)
{
    OEM4API_CANSend(CAN1, pstMyCANFrame, FALSE);
}
```

Without a `TaskSleep` the CPU can fill the transmit queue much faster than can be read out and transmitted on a CAN bus by the CAN protocol hardware even at a bus rate of 1 Mbps.

The sleep interval for `TaskSleep` is chosen based on bus rate, frame size and bus conditions. An extended CAN frame, with the maximum 8 data bytes is 127 bits.^[7] A collision-free bus minimizes the inter-frame space to just 3 “frame intermission” bits, which can be considered part of the CAN frame for this discussion (total frame size becomes 130 bits).

At a bus rate of 1000 kbps, the bit period is 1 μ s. Transmitting a single frame on this bus will take approximately (130 x 1 = 130 μ s). A `TaskSleep` interval of approximately (32 frames x 130 μ s), rounded up to 5 ms, would suffice to allow a 32 frame burst to empty out the transmit queue.

Alternatively, at a bus rate of 125 kbps, the bit period is 8 μ s. A single frame takes approximately (130 x 8 \approx 1 ms) to transmit and therefore a `TaskSleep` of 32 frames (at least 32 ms; ideally more) is required to empty the transmit queue at this bus rate.

Note that these calculations assume ideal bus conditions (no collisions or errors) and serve only to guide the system integrator in developing applications for their own particular CAN bus requirements.

A frame burst of 32 or fewer frames at a time results in no lost frames *if* the `TaskSleep` interval between frame bursts is sufficiently large. The system integrator must choose the `TaskSleep` interval (perhaps 20 ms) to ensure all frames transmit after a burst taking into account the bus rate and bus congestion. The example code below shows how two successive frame bursts with an interleaved `TaskSleep` can succeed without dropping frames.

```
For(int i = 0; i < 32; i++)
{
    OEM4API_CANSend(CAN1, pstMyCANFrame, FALSE);
}

// wait until previous burst has made it out onto the bus
OEM4API_TaskSleep(20); // sleep for 20 milliseconds

// burst more frames
For(int i = 0; i < 32; i++)
{
    OEM4API_CANSend(CAN1, pstMyCANFrame, FALSE);
}
```

Tips

- 1) If it is necessary to burst frames, do not exceed 32 frames per burst.

- 2) The `bBlock_` parameter should be set to `FALSE` to realize maximum application performance.

Frame Reception

CAN frames are automatically received from the CAN bus by the CAN protocol hardware. The API functions, responsible for receiving CAN frames, see only those CAN frames that pass hard and soft filters. These API functions are:

- `OEM4API_CANNumRxMsgs`
- `OEM4API_CANReceive`

CANNumRxMsgs

`int`

```
OEM4API_CANNumRxMsgs(
    CANPortEnum ePort_ );
```

Poll the reception queue status for `ePort_` by calling this function. `CANNumRxMsgs` returns the number of messages waiting in the reception queue. These messages have passed all filters. Retrieve them via `CANReceive`.

CANReceive

`BOOL`

```
OEM4API_CANReceive(
    CANPortEnum ePort_,
    CANMsgStruct* pstCANMsg_,
    unsigned int uiTimeout_ );
```

`CANReceive` scans the receive queue for the specified port, `ePort_`, and returns the next pending message in `pstCANMsg_`. If `uiTimeout_ = 0`, the user task blocks and waits indefinitely until a message is available. If `uiTimeout_` is non-zero, the user task waits until it receives a message, or the time out expires. If the time out expires before it receives a message, the function returns `FALSE`.

CAN frames received from the CAN bus are subjected to hard and soft filtering. If the frame ID matches a hard filter, then soft filtering applies. If the frame ID (and optionally the first 2 bytes of data) matches any installed soft filters, the frame goes into the reception queue and is visible to the `CANReceive` and `CANNumRxMsgs` functions. If there are no soft filters installed, all frames passing the hard filters are visible. If `CANReceive` was previously called with `uiTimeout_ = 0`, or a specified timeout has not expired, and the receive queue was empty, the waiting user task is notified of the newly received message and the user task resumes.

Similar to the transmit queue, the reception queue holds up to 32 CAN frames. If there is no `CANReceive` call before it reaches the 32-frame limit, the 33rd frame is lost. To avoid losing frames by exceeding the reception queue limits ensure that:

1. Hard filters pass only required messages.
2. The transmitter does not burst more than 32 frames.
3. Application code, responding to messages received from `CANReceive`, completes in a timely manner.

Tip

For maximum application performance, consider checking for pending messages in the reception queue with `CANNumRxMsgs` first. If there are pending messages, `CANReceive` may be repeatedly called with `uiTimeout_ = 0` to retrieve them.

Special Notes on Filtering

The ability to filter frames is a key feature of CAN. A CAN node is typically interested in only a small portion of the total data traffic on the CAN bus. By providing the ability to filter out unwanted messages, the CAN node can significantly reduce the CPU cycles (and power) required to manage CAN communications.

The hard filters and, to a lesser extent, soft filters have been created for this purpose. Therefore, correct usage of the filters is critical to successfully implementing CAN. Shown in *Figure 5* below, hard CAN filters filter out CAN frames *before* they consume any CPU cycles. The software implements soft filters and consumes CPU resources. However, soft filters can provide an extra line of defense to prevent user application code from unnecessary execution.

Rule: If no more than 16 filters are required, and data byte filtering is not required, use only hard filters.

Following this simple rule ensures maximum application performance.




Figure 5 NovAtel’s CAN Filter Configuration

Hardware Filtering Using `HardCANFilterStruct`

```
typedef struct
{
    BOOL bInUse;
    BOOL bExtended;
    unsigned long ulAcceptanceCode;
}
```

```

    unsigned long ulAcceptanceMask;
} HardCANFilterStruct;

```

The code and mask bits used to define hardware filters are indicated in *Table 1* below. A '1' bit means, "This bit is used to define the code/mask".

Table 1: Hard Filter Code and Mask Bit Definitions

	Extended Frames	Standard Frames
ulAcceptanceCode	0x1FFF FFFF	0x1FFC 0000
ulAcceptanceMask	0x1FFF FFFF	0x1FFC 0000

Bits 0-28 filter the 29-bit message identifier of extended frames if `bExtended = TRUE`. Bits 18-28 filter the 11-bit message identifier of standard frames if `bExtended = FALSE`.

A '0' bit in the mask indicates that the corresponding bit in the code is used for acceptance filtering. A '1' bit in the mask indicates that the corresponding bit in the code is *not* used for acceptance filtering (that code bit may be ignored).

Extended frame examples:

```
ulAcceptanceMask = 0x1FFF FFFF
```

```
ulAcceptanceCode = 0xFFFF FFFF -> accept all messages regardless of
code bits (X = don't care)
```

```
ulAcceptanceMask = 0x0000 00F0
```

```
ulAcceptanceCode = 0x0000 0AX3 -> accept extended message IDs in the
range [A03, AF3] ([2563, 2803]10)
```

Software Filtering Using SWCANFilterStruct

```

typedef struct
{
    unsigned long ulCode;
    unsigned long ulMask;
    unsigned short usExtCode;
    unsigned short usExtMask;
} SWCANFilterStruct;

```

Apply software filters to CAN frame IDs in the same way as hard filters. The system integrator can also simultaneously apply software filters to the first two data bytes of a CAN frame by appropriately setting the bits of `usExtCode` and `usExtMask`. *Table 2* on *Page 12* indicates the code and mask bits used to define software filters. A '1' bit means, "This bit is used to define the code/mask".

Table 2: Soft Filter Code and Mask Bit Definitions

	Extended Frames	
ul AcceptanceCode	0x1FFF FFFF	
ul AcceptanceMask	0x1FFF FFFF	
usExtCode	0x	FFFF
usExtMask	0x	FFFF

Bits 0-28 of the acceptance mask, and acceptance code, filter the 29-bit message identifier of extended frames. Apply Bits 0-7 of the usExtCode and the usExtMask words to the first data byte. Apply Bits 8-15 of the usExtCode and the usExtMask words to the second data byte.

A '0' bit in the mask indicates that the corresponding bit in the code is used for acceptance filtering. A '1' bit in the mask indicates that the corresponding bit in the code is *not* used for acceptance filtering.

Diagnostics

An essential component of creating a CAN application is to ensure that the system integrator can test it. A loopback routine is available from NovAtel Customer Service upon request.

The loopback routine simultaneously transmits and receives CAN frames between CAN1 and CAN2 configured for 1 Mbps/s. The system integrator must connect a properly configured CAN bus between CAN1 and CAN2 (see *Figure 1 CAN Physical Layers on Page 1*).

Both CAN1 and CAN2 transmit extended frames at 2 ms intervals. The ID for frames transmitted from CAN1 start at 0x10000000. The ID for frames transmitted from CAN2 start at 0x1FFFFFFF. The ID increments by 1 after each successful transmission (OEM4API_CanSend() returns TRUE). Note that a successful transmission does not necessarily indicate a successful reception.

The length of the data transmitted in each frame cycles from 0 to 8 bytes. Frame data bytes contain the values in the range [0x30 to 0x37].

For every 100 frames CAN1 successfully transmits, the following message displays on COM1:

TX1/RX2 100/99/0, TX2/RX1 100/99/0

TX1/2 = the number of successful frame transmissions from CAN1/2

RX1/2 = the number of frames received on CAN1/2

CAN1 (TX1) transmits frames to CAN2 (RX2) and CAN2 (TX2) transmits frames to CAN1 (RX1).

The last parameter (0 in the example) is the number of frames lost. Calculate this number as:

$$\text{number of lost frames} = \text{number of received frame IDs} - \text{number of expected frame IDs}$$

For each frame the CAN successfully receives, the expected frame ID sets to the received frame ID plus one.

On an error-free bus, the number of frames received from a CAN port are always 1 less than the number of frames transmitted from the same CAN port:

$$\text{RX2} = \text{TX1} - 1$$

Conclusion

The NovAtel receiver implements the CAN protocol using the NovAtel API and a third party CAN protocol stack. The NovAtel API enables the system integrator to configure the CAN 2.0 processor with the appropriate filtering masks to permit interoperability of the NovAtel GNSS receiver on a CAN bus network.

References

- [1] See NXP Semiconductor Application Note for more details on the evolution of CAN:
http://www.nxp.com/acrobat_download/applicationnotes/AN92002.pdf
- [2] <http://en.wikipedia.org/wiki/CANopen>
- [3] <http://en.wikipedia.org/wiki/DeviceNet>
- [4] The *Application Program Interface (API) User Guide*, with part number OM-20000074, is available from NovAtel Customer Service when you have an API receiver model. NovAtel contact details are in the *Final Points* section below.
- [5] <http://www.novatel.com/Documents/Manuals/om-20000093.pdf>
- [6] <http://www.can-cia.org/index.php?id=517#c2068>
- [7] http://en.wikipedia.org/wiki/Controller_Area_Network

Final Points

If you require further information, regarding the topics covered by this document, please contact:

NovAtel Customer Service

1120 – 68 Ave. N.E.

Calgary, Alberta, Canada, T2E 8S5

Phone: +1-800-NOVATEL (in Canada or the U.S.) or +1-403-295-4500

Fax: +1-403-295-4901

E-mail: support@novatel.com

Website: www.novatel.com